

# ENTRY GATE OPERATION

## USER INSTRUCTIONS FOR THE DOOR KING GATE ENTRY SYSTEM

Your neighborhood has been equipped with a Door King Gate Entry System. Please read these instructions carefully to familiarize yourself with the proper procedures for using the system. **Please notify CAM Pros (386-366-0288) of your new phone number so he can program your information into the gate directory.**

1. The System uses your existing telephone to let you talk with visitors and allow them access if you so desire. A visitor is instructed to find your “code” on the system’s built-in electronic directory and enter your code on the keypad. The system then dials your telephone number, which has already been programmed into the system’s memory and your telephone will ring. The system will keep your number confidential.
2. Upon answering the telephone, you will be in a normal conversation with the visitor. Be sure to speak clearly and strongly so the visitor can hear you over any noise near the gate. The call can only last for a limited amount of time (set by Association management). After that period, the system will automatically end the call to ensure the system is available to other visitors. Starting 10 seconds prior to the end of the call, you will begin to hear a short tone each second to signal you the call is about to end.
3. Once you have answered the call, you may take one of two actions:
  - a. Dial a “9” to open the gate.
  - b. Dial a “\*” to hang up without granting entry
4. If you dialed a “9”, the system will unlock the gate for a preset period of time. The system will also display the message, “ACCESS GRANTED-PLEASE ENTER NOW” and emit short tones for 3 seconds. After you hear these tones, the system will hang up.
5. If you are on the telephone when a visitor tries to call you, he or she will receive a busy signal unless you have Call-Waiting. Therefore, be brief with your telephone calls, if you are expecting company, so your visitor does not have to wait long to reach you. If you have Call-Waiting, you can simply switch over to the call from your visitor, let him or her in, then go back to your original call.
6. You can also enter by using your Remote Transmitter.
7. You can also enter by using your personal 4 digit code by pressing the # symbol first and then entering the 4 digit code assigned by the Association Management when you purchased.
8. To exit, just approach the exit gate slowly and the gate will automatically open.