PRODUCT OVERVIEW

Stone-01 is a city delivery robot for both indoor and outdoor comprehensive coverage. It specifically addresses the "last-mile" autonomous doorstep delivery challenge, empowering courier operations, property management, and food delivery services. Stone-01 is compact and agile, capable of operating in multiple scenarios including business districts, communities, airports, and campuses. It features unmanned precise delivery, mobile app ordering, intelligent locker doors, autonomous charging, and other functionalities. It has low operational costs and facilitates property management, empowers businesses, and provides convenience to consumers.



TABLE OF CONTENTS

Product Overview	1
Chapter 1. Main Features	4
1. Autonomous Mapping	4
2. Autonomous Obstacle Avoidance	4
3. Intelligent Detection:	4
4. Doorstep Delivery	4
5. Mobile App Ordering	4
Chapter 2. User Manual	5
1. Basic Operations	5
2. Joystick Control	5
2.1 Joystick Introduction	5
3. Charging Methods	6
3.1 Manual Charging	6
4. Autonomous Mapping	7
5. Delivery App	8
5.1 Delivery Side	8
5.2 Customer Side	
5.3 Operations Side	

WWW.SOPHON-AUTO.COM

CHAPTER 1. MAIN FEATURES

1. AUTONOMOUS MAPPING

Users can manually control Stone-01 via a joystick to collect map data and complete autonomous mapping without the need for mapping providers.

2. AUTONOMOUS OBSTACLE AVOIDANCE

Equipped with the SOPHON Pangu autonomous driving system, Stone-01 can patrol indoors and outdoors autonomously, plan optimal routes, recognize obstacles, and features kilometer-level path planning, centimeter-level precision positioning, and millimeter-level obstacle avoidance.

3. INTELLIGENT DETECTION:

Facial Recognition: Real-time dynamic detection of individuals within the campus, with a pre-entered facial data database allowing for facial recognition.

Identity Verification: Ensures secure delivery to designated individuals via AIOT.

4. DOORSTEP DELIVERY

Stone-01 can connect to building elevator systems to autonomously ride elevators: set the destination floor, ride the elevator, and complete the delivery.

5. MOBILE APP ORDERING

An accompanying app allows for autonomous order placement, scheduled delivery timing, real-time delivery tracking, and delivery confirmation via phone and SMS.

CHAPTER 2. USER MANUAL

*Please read the following terms carefully before using the robot and use the robot correctly as instructed.

1. BASIC OPERATIONS

Pre-Startup Check: Ensure the robot is in good condition before starting.

Startup: Power on the robot by pressing the power button at the back.

Shutdown: Turn off the robot by pressing the power button at the back.

Post-Shutdown Cautions: The robot should remain stationary after shutdown to avoid hardware damage.

Emergency Stop: Use the emergency stop button at the back of the robot to halt movement and prevent damage or injuries.

*Once the robot is in emergency stop mode, it should not be forcibly moved to avoid hardware damage. Emergency stop can only be disengaged after manual inspection and repair are complete.

2. JOYSTICK CONTROL

Each Stone-01 comes with a joystick for initial setup and map creation, already paired with the robot. The joystick may not be needed after initial use.

2.1 Joystick Introduction



3. CHARGING METHODS

Stone-01 supports autonomous and manual charging. It comes with a dedicated autonomous charging station and a charger for manual charging.

3.1 Manual Charging

The robot's rear is equipped with a charging port. To charge, connect the charger to the port and a power socket. Always observe electrical safety during charging.





4. AUTONOMOUS MAPPING

To use Stone-01 for the first time, you must create inspection maps and configure them accordingly. Ensure you can log in to the Stone-01 inspection robot cloud platform before starting.

Autonomous Mapping Process:

- \bigcirc Power on
- \odot Control Stone-01 using the joystick
- ③ Start autonomous mapping; upload maps to the Web
- A Save the mapping data
- **Set inspection no-go zones as needed**

*Note: For structurally complex campuses, separate mapping for different areas might be required before merging the maps, which can be a complex process. Contact after-sales service for assistance with mapping.

5. DELIVERY APP

The delivery app is divided into delivery, customer, and operations sides.

Delivery Side: Used by merchants to view the operational status and historical results of individual robots.

Customer Side: Allows customers to place orders online and view the delivery status of the delivery robot.

Operations Side: Used by the management platform for robot management and basic settings, such as adding robots, viewing vehicle information, configuring vehicles, building maps, and issuing tasks.

5.1 Delivery Side

10:17 🕫		ul ? ■	10:17 🗸			h.	≈ ■ ·
ヨレヘロ ②性价比高 ③	へ ROCK 1 保证时效		ヨレハ ④性价比高	。 () 保证时效	℃はしていていていていていていていていています。		
Q、每天搜索订5	单/机器人		Q、每天携	提索订单/机器人			
巿	1.器人	订单		机器人		订单	
関 机器编号: (60669		今日订单	全部			
50	机器状态:已分配, 订单编号:67893454 订单编号:67893454	可装载。 5876 5876	80 ≎□€) D	区 60 ^{进行中}	[2 20 三完) D
机器电量 80%	机器	容量 3883 7/9	进行中 🗆 🖯	2完成 全部订	"单		
■ 机器编号: (60669 机器状态: 已分配,	可装载。	机器编号: 60 订单编号: 67 _{朝阳区 望京街} (*	0669 789 3454 5876			>
17 3	订单编号: 6789 3454 订单编号: 6789 3454 	5876 5876	机器编号: 60 订单编号: 67 朝阳区 望京街**	0669 789 3454 5876 ******			>
机器电量 80%	机器	容量 3823 7/9	机器编号: 60 订单编号: 67 朝町区 呈 _{京街**}	0669 789 3454 5876 ******			>
📕 机器编号: (60669		机器编号: 60 订单编号: 67	0669 789 3454 5876			>
5	机器状态: 已分配, 订单编号: 6789 3454 订单编号: 6789 3454	可装载。 5876 5876	朝阳区 至京衛共 机器編号: 60 订单编号: 67 朝阳区 至京街中	2669 289 3454 5876			>
開設	日	24		流息	85	≑t	2000 1000 1000 1000 1000 1000 1000 1000

The bottom menu of the app allows users to monitor the robot's delivery status, battery level, and cargo load. Order details and completion statistics can be viewed by selecting the relevant robot.



Clicking on a robot shows its current ID, battery level, and capacity. Manual takeover is possible for real-time monitoring of the robot's environment and control during emergencies.



For new orders, select the robot for cargo loading, enter order details by clicking "Record Order," and track the delivery status once entered.



Flowchart for Delivery Side Usage

5.2 Customer Side

After entering the ordering app, customers can choose "Machine Delivery" from the menu to shop for products.



At checkout, select a delivery address or create a new one by entering regional and

contact details.

:17 - 7		al 🗟 🔳					10:17	1		-ail *
	确认订单	@	Ð				<	新	建地址	
							姓名	语输λ 姓名		
_							「手机	请输λ手机号		
	80						1.00	C DU C XUMPHI		
							省市	☑ 请选择省市区		
选择收货地址	Ł	>					详细	地址 如道路、小区。	、大厦、门牌号	
本单由机器人提供	共配送服务。									
橙之港	每生酪拿铁	¥14.	4							
冰/少刮 募后价	註/訳认奶油 ₹	¥3 ×	1							
端幸优惠		-¥28.6	~							
		应付 ¥ 32.4	4							
专付方式		😪 微信支付 >								
备注特殊要求		,								
提示:建议您按焉点单。 往发莱管理中开具。	杜绝浪费,本单仅支持	开具电子发票,订单完成	R./16							
∀ ¥ 32.4		去支付							保存	
付¥32.4 计优黑¥28.6		去支付							保存	
寸 ¥ 32.4 优無 ¥ 28.6 		去支付 ━	10:17 🕫			ul ≎ ■	10:17 🗸		保存	
t ¥ 32.4 (大無 ¥ 28.6 17 -√	新建地址	去支付 	10:17 -₹ <		新建地址	-ul ≎ ■ 	10:17 /	新建地址	保存 I 令 = 6	u•
t ¥ 32.4 代墨¥28.6 :17 √ 名 王饌字	新建地址	去支付 ,I 중 (里) (++ ⊙)	10:17 √ く 姓名	王假字	新建地址	-ul ♀ ■ 	10:17 ¢ <	新建地址	保存 	•
ty ¥32.4 :(抗果¥28.6 ::17 -7 名 王健宇 和 131000088	新建地址	去支付 (? ■) ()	10:17 イ く 姓名 手机	王假字 131000088	新建地址 388	.ıl २ ■ (••• 0	10:17 <i>-4</i> 《 姓名	新建地址 王假字 13100008888	保存 Iマ ■ ()	
tri ¥ 32.4 tritme ¥ 28.8 :17 √ :17 √ :名 王段字 机 131000088	688 1913	去支付 	10:17 4 く 姓名 手机 省市区	王假字 131000088 北京市 朝鮮	新建地址 388		10:17 √ < 姓名 手机	新建地址 王候字 13100008888	<u>保存</u> ? ■	
t ¥ 32.4 快要 ¥ 28.6 177 イ 名 王健宇 机 131000088 市区 请送择省市 編曲社 411111	新建地址 888 区	去支付 II ? ■ . 	10:17 √ く 姓名 手机 背市区 详细地址	王假字 131000088 北京市 朝鮮	新建地址 388 BIX	■ \$ IL)))))))))))))))))))	10:17 <i>-1</i> く 姓名 手机 省市区	新建地址 王傑字 1310000888 北京市朝阳区	保存 	
th ¥ 32.4 (伏果 ¥ 28.6 :17 √ 名 王健字 机 131000088 市区 请选择省市 細地址 如道路、小	新建地址 88 図 図、大庫、门牌号	去支付 	10:17 √ く 姓名 手机 音市区 详细地址 详细地址	王假字 131000088 北京市朝期 如道路、小	新建地址 388 HE NG、大匠、门碑号	■ ? II. ••• ••• • • •	9 10:17 √ く 姓名 手机 省市区 详细地址	新建地址 王健学 13100008888 北京市 朝阳区 望京SOHO T2 A座 12	保存 1 マ ■ 	
th ¥ 32.4 (代果 ¥ 28.6 (代果 ¥ 28.6) 名 王健李 和 131000088 市区 请选择省市 細地址 如道路、小 市地区 2) (体4)4時/16/17/76	新建地址 88 区、大厦、门牌号	去支付 	10:17 - 4 建名 手机 省市区 详細地址 详细地址 Q SOHO	王假字 131000088 北京市朝即 如道路、小 上	新建地址 388 H区 AIX、大匠、门牌号	■ ≎ II. • • •	10:17 4 く 姓名 手机 省市区 详细地址	新建地址 王健学 13100008888 北京市 朝阳区 望京SOHO T2 A座 12	<u>保存</u> ? ■ : : : : : : : : : : : : : : : : : : :	
tri ¥ 32.4 1快車 ¥ 28.8 1:17 √ ※名 王段字 和 1310000888 市区 请选择省中: 細地址 如道路、小 市地区 2 请職入省份/版市/市区 省份	新建地址 新建地址 88 区 区、大厦、门牌号 区型会 城市	去支付 	10:17 - * く 姓名 手机 谐市区 详細地址 详細地址 Q、SCHC 极称	王假字 131000088 北京市朝昭 如道路、小 上	新建地址 388 H区 V区、大匠、门牌号 单元	.:ll 字 ■ ③ ③ 	10:17 √ 人 姓名 手机 省市区 详细地址	新建地址 王假字 13100008888 北京市 朝阳区 望京SOHO T2 A座 12	<u>保存</u> 1 マ ■ 	
t ¥ 32.4 (代展 ¥ 38.6 :17 -7 名 王段字 机 131000088 市区 请选择省中 細地址 如道路、小 市地区 2 请徳入省份/城市/市臣 省份	新建地址 88 図 図、大厦、门線号 33次 城市	去支付 	10:17 -/ 姓名 手机 省市区 详細地址 详細地址 Q. SOHC 极称	王假字 131000088 北京市 朝即 如道路、小 上	新建地址 3888 BIX V区、大匠、门牌号 单元	- \$ الـ • • • • • • • • • • • • • • • • • • •	10:17 4 人 好名 手机 省市区 详细地址	新建地址 王傑字 1310000888 北京市 朝阳区 望京SOHO T2 A座 12	<u>保存</u> 	
ty ¥ 32.4 (次集 ¥ 32.6 二 二 二 二 二 二 二 二 二 二 二 二 二	新建地址 88 区 区、大厦、门牌号 区域尔	去支付 	10:17 - 姓名 手机 省市区 详细地址 详细地址 Q SOHC 极称	王假字 131000088 北京市朝印 如道路、小 上	新建地址 388 H区 	.山々 ● () () () () () () () () () ()	10:17 4 人 姓名 手机 省市区 详细地址	新建地址 王傑字 13100008888 北京市 朝阳区 望京SOHO T2 A座 12	<u>保存</u> ? ■ : ···· @ 210 ~	
t ¥ 32.4 (代果 ¥ 28.6 17.4 名 王健宇 和 131000088 市区 语送择省市 細地址 如道路、小 市地区 2 请味入資份/城市/市臣 沓份	新建地址 88 図 図、大厦、门牌号 図本 北京市	去支付 	10:17 - f 姓名 手机 省市区 详細地址 详細地址 (Q. SOHO 极林 望京SOH	王假字 131000088 北京市朝阳 如道路、小 上	新建地址 3888 H区 (区、大匠、门牌号 单元 A座	11 个 = 	10:17 4 人 姓名 手机 省市区 详细地址	新建地址 王賢字 13100008888 北京市 朝阳区 望京SOHO T2 A座 12	<u>保存</u> 1 マ = : ・・・ (210 ~	
th ¥ 32.4 (快要 ¥ 28.6 17.4 名 王健宇 和 131000088 市区 语法指音市 細地址 如道路、小 市地区 2 请端入省份/城市/市臣 省份 北京 天津	新建地址 88 図 図 、大厦、门牌号 工業会 城市 北京市	大大大 ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	10:17 - 7 姓名 手机 省市区 详細地址 详细地址 Q、SOHC 极称 望京SOH 三里电SOF	王假字 131000088 北京市朝即 如道路、小 上 5	新建地址 3888 HI区 N区、大匠、门碑号 単元 A座 日座	.北京 中 ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・	10:17 4 く 姓名 手机 省市区 详细地址	新建地址 王健宇 13100008888 北京市 朝阳区 望京SOHO T2 A座 12	保存 ? = : ···· (2 210 、	
t ¥ 32.4 (代集 ¥ 28.6 17.7 名 王保字 和 131000088 市区 诵选择省市 細地址 如道路、小 市地区 2 (14年入省份/城市/市匠 省份 北京 天津 河北省	新建地址 88 区、大厦、门牌号 区、大厦、门牌号 北京市	大大大 ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	10:17 - * 《 姓名 手机 省市区 详细地址 (SOHC 极称 望京SOH 三里电SOF 建介SOH	王假字 131000088 北京市朝郎 如道路、小 上 〇 〇	新建地址: 3888 H区 以区、大匠、门碑号 単元 日座 日座 C座	・川 マ ■ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・	10:17 4 く 姓名 手机 省市区 详细地址	新建地址 王母字 13100008888 北京市 朝阳区 望京SOHO T2 A座 12	<u>保存</u> 1 マ = : ···· (2 210 ~	
th ¥ 32.4 (代集 ¥ 28.6 17.7 名 王保字 和 131000088 市区 诵选择省市 細地址 如道路、小 市地区 2 (14年入省份/城市/市匠 客份 北京 天津 河北省 山西省	新建地址 88 区、大厦、门牌号 工業会 北京市	大大大 ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	10:17 - 4 建名 手机 省市区 详細地址 (2 SOHC 极称 望京SOH 三里电SOH 遅/SOH	王假字 131000088 北京市朝郎 如道路、小 上 〇 〇	新建地址: 888 H区 人区、大匠、门碑号 単元 日座 日座 C座	・川 マ ■ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・	10:17 4 人 姓名 手机 省市区 详细地址	新建地址 王健学 13100008888 北京市 朝阳区 望京SOHO T2 A座 12	<u>保存</u> マー : : : : : : : : : : : : : : : : : : :	
t ¥ 32.4 t t ¥ 32.4 t t t 第 ¥ 32.6 T 7 7 名 王母子 和 131000088 市区 诵选择省印 細地址 刻道路、小 市地区 2 (编本)46/46币/布匝 審份	新建地址 88 区 区、大厦、门牌号 23法 城市	大大大 ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	10:17 - 4 建名 手机 省市区 详細地址 详細地址 建京SOH 運京SOH 建介SOHO現代 期外SOH	王假字 131000088 北京市朝印 如道路、小 上 5 (0) HO (0) (1) (1) (1) (1) (1) (1) (1) (1) (1) (1	新建地址 3888 B区 (文、大匠、门碑号 単元 日座 日座 (工座	11 个 一 (1) (1) (1) (1) (1) (1) (1) (1) (1) (1)	10:17 4 人 姓名 手机 省市区 详细地址	新建地址 王母字 13100008888 北京市 朝阳区 望京SOHO T2 A座 12	<u>保存</u> 1 マ = : ・・・ (210 ~	
rty ¥ 32.4 (+t代基 ¥ 22.6):17 √ 注名 王母字 活化 131000088 清市区 请选择省印 詳細地址 如道路、小 注市地区 ① 请读入省份/城市/市区 省份 北京 天津 河北省 山西省 蒙古自治区 辽宁省	新建地址 88 区 区、大厦、门牌号 工業大	大大大 ・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・・	10:17 - 4 建名 手机 省市区 详細地址 详細地址 (2 SOHC 優林 望京SOH 建介SOH 現分SOH 中美村SOH	王假字 131000088 北京市朝印 如道路、小 上 	新建地址 3888 BI区 、大匠、门碑号 単元 日底 日底 こ座	11 个 一 (1) (1) (1) (1) (1) (1) (1) (1) (1) (1)	10:17 4 人 姓名 手机 省市区 详细地址	新建地址 王母字 13100008888 北京市 朝阳区 望京SOHO T2 A座 12	<u>保存</u> 	
tri ¥ 32.4 + 代東 ¥ 22.6 	新建地址 88 図 図、大厦、门線号 4 本 1 北京市	去支付 → 1 (* ●) → (*)	10:17 - 4' メ 建名 手机 省市区 详細地址 详細地址 详細地址 详細地址 建京SOH 屋東市SOH 建介SOH ジントの現代 明外SOH 中美村SOH 原泽SOH 原泽SOH	王假字 131000088 北京市朝師 如道路、小 上 5 100 日〇 〇 〇 日〇 〇 〇 日〇 〇	新建地址 3888 H区 、大匠、门牌号 単元 の座 の座	11 个 一 (1) (1) (1) (1) (1) (1) (1) (1) (1) (1)	10:17 4 人 姓名 手机 省市区 详细地址	新建地址 王假字 1310000888 北京市 朝阳区 望京SOHO T2 A座 12	<u>保存</u> 	
(1 ¥ 32.4 (1) (秋葉 ¥ 28.6 (2) (17 *) (2) (17 *) (2) (17 *) (2) (17 *) (3) (18 *) (4) (18 *) (5) (18 *) (5) (18 *) (7) (18 *) (7) (18 *) (8) (18 *) (7) (18 *) (8) (18 *) (7) (18 *)	m建地址 88 区 区、大恒、门線号 工 工 本 、 、 、 、 、 、 、 、 、 、 、 、 、 、 、 、 、	去支付 → 1 (2) → → (2)	10:17 - 4' メ メ メ メ オ市区 オ市区 洋畑地址 详細地址 洋畑地址 洋畑地址 洋畑地址 建京SOH 慶家 SOHO現代 朝外SOH 中关村SOH 元澤SOH 光华路SOH	王假字 131000088 北京市朝鮮 如道路、小 上 し い に 低 い い 日 い い い	新建地址 388 BIE 、大匠、门練号 単元 の座 の座	・川 マ ■) ・・・ ○ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・	10:17 4 人 好名 手机 省市区 详细地址	新建地址 王假字 1310000888 北京市 朝阳区 望京SOHO T2 A座 12	<u>保存</u> 	
(1 ¥ 32.4 (1) (秋葉 ¥ 28.6 (2) (17 - 7) (2) (17 - 7) (2) (17 - 7) (2) (17 - 7) (2) (17 - 7) (3) (16 - 7) (4) (16 - 7) (5) (16 - 7) (5) (16 - 7) (5) (16 - 7) (6) (16 - 7) (7) (16 - 7)	新建地址 88 区 区、大臣、门勝号 ご 電太 城市	大文付 ・11 ⑦ ●) ・1 ⑦ ・1 ⑦ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・	10:17 - 4 父 姓名 手机 省市区 详細地址 详細地址 详細地址 详細地址 建京SOH 三里电SOF 違外SOH SOHO現代 朝外SOH 空景空の日 第外SOH 第米SOH 東洋松谷 東洋公	王伊字 131000088 北京市 朝鮮 加速浩、小 上 し い に の 日 の の 日 の の 日 の の の 8 の の の 8 の の の 8 の の の 8 の	新建地址 888 R区 レ 、大広、门線号 単元 日底 日底 こ座	・山 マ ■ ・・・ ○ ・・・ ○ ・・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・ ・	10:17 4 人 生名 手机 省市区 详细地址	新建地址 王賢字 13100008888 北京市 朝阳区 望京SOHO T2 A座 12	<u>保存</u> 	

Once ordered, track the robot's delivery distance and time, with options to cancel the order, contact the merchant, or modify the delivery address.

		A H H H H H H H H H H
4:16 -		al 🗢 🔳
1号楼	2号楼	
● ^{悠然足道}		3号楼 ••• ④
●麦田房产	宝星华庭公寓	48
*		
	机器人正在面	Citie O state
	· · · · · · · · · · · · · · · · · · ·	THP VICKII J
-	- 0	DOM OF SELECT
	00	
		D ELES
		融料橄榄 〇
10-1	2.0	#en⊔nnat
新计14·25计	¥ì大	
1001 14.202		
	()	0
[3:前1)年	法定面示	# 2315-34
深前14	₹ ₩₩	18.372.9
3%)/#	_{速系向家} ← 一键取货	WEXUS #
	^{,援承前家} (」一键取货	42iX#
R#U#	- まる高家 (1) 一 健取扱	RX15.#
RHU#	**## () 一键取扱 橙之海生酪拿铁 ** (小田 (#2) (#2)	15.55.4 ¥ 14.4
3m 4	**## (二一谜取货 替之海生酪拿铁 冰/少甜/默认奶油	¥14,4 ×12 × 14,4
Smil#	**## (二一健取後 他 一 他 一 他 取 後 他 本 の 、 一 他 取 後 他 本 の 他 の 後 他 本 の 他 の 後 他 本 の 他 本 の 他 本 の 他 本 の 他 本 の 他 本 の 一 他 の の 他 本 の 一 他 の の の し の の し し	95355 ¥ 14,4 ¥ 32 × 1
RăI 4	**## (二一健取扱 増之海生酪拿鉄 冰/少甜/默认防油 夢品价	97395.2 ¥ 14.4 ¥ 32 × 1
3前14 3前14 瑞幸优惠	**## <u> 一</u> 一健取货 着之海生酪拿铁 冰/少甜/默认奶油 夢后价	₩235# ¥14.4 ¥32 × 1 -¥28.6 ~
3前14	**## <u> 一</u> 一健取货 着之海生酪拿铁 冰/少甜/默认奶油 夢后价	₩236# ¥14.4 ¥32 × 1 -¥28.6 ¥
2014 2014 瑞幸优惠	#¥## <u> 合</u> 一键取扱 檀之海生酪拿铁 冰/少甜/默认奶油 夢后价	#236.# ¥14.4 -¥28.6 ~ 应付 ¥32.4
2前1年 2前1年 瑞幸优惠	**## (二一健取後 着之海生酪拿鉄 冰/少甜/默认坊油 夢后价	#236.# ¥14.4 ¥32 × 1 -¥28.6 ~ 应付¥32.4
2前1年 2前1年 瑞幸优惠	#### (二一谜取後 着之海生酪拿铁 冰/少甜/默认奶油 夢后价	#236.# ¥14.4 -¥28.6 ~ 应付¥32.4
23年0年 23年0年 瑞幸优惠	#### (二一健取版 着之海生酪拿铁 冰/少胡/新认奶油 夢后价	#3353.# ¥14.4 ¥23 × 1 -¥28.6 ~ 应付¥32.4 立3P763送
Image: Image	#### (二一健取货 着之海生酪拿铁 冰/少甜/飲い奶油 夢后价 創た区 望东(1)(3 主	#335# ¥14,4 ¥22 × 1 -¥28.6 × 应付¥32.4 业立印候起 全国所能达 集(豊富SOHOTZA)筆1210
23年0年 23年0年 33年 33年 33年 33年 33年 33年 33年	#### () 一键取货 管之海生酪拿铁 冰/少甜/默认奶油 夢后价 新院区 望东(11)6 土	#335# ¥14.4 ¥22 × 1 -¥28.6 ~ 应付 ¥32.4 注意所らば2 # 歴気SOHOTZA筆 [27] ** (先王) 123***1234 大振讯器人玩送
23年0年 23年0年 33年 33年 33年 33年 33年 33年 33年	#### () 一键取货 借之海生酪拿铁 冰/少甜/做认奶油 勞后价 新E区 空东气108 王	#236# ¥14.4 ¥22 × 1 -¥28.6 ~ 应付 ¥32.4 注意PF6述 案 歴界SOHOTZA选 [27] **(供生) 123***1234 天飯現容人死送 安容69
23年0年 23年0年 第二年 第二年 第二年 第二年 第二年 第二年 第二年 第二	#### () 一键取货 管之海生酪拿铁 冰/少甜/做认奶油 夢后你 新E区 空东气108 王	#2352 ¥14.4 ¥22 ×1 -¥28.6 ~ 应付 ¥32.4 注意PFG达 全意PFG达 全意PFG达 全意PFG达 全意PFG达 全意PFG达 全意PFG达 全意PFG达 全意PFG达 全意PFG达 会合の 会の 会の 会の 会の 会の 会の 会の 会の 会の 会
23年0年 23年0年 23年 23年 23年 23年 23年 23年 23年 23	#### () 一键取货 管之海生酪拿铁 冰/少甜/做认奶油 第后价 新庄区 望东(s108 土	#335# ¥14.4 ¥22 × 1 -¥28.6 ~ 应付¥32.4 注意PRE述 集盛第80H0T2人達 [27] ※ (先生) 123#5+1234 天新机器人形述 60669 溢和手引号、保約5年1
2014 2017 2017 2017 2017 2017 2017 2017 2017	#### (二一键取数 借之海生酪拿铁 冰/少祖/默认奶油 夢后か 新店区 空気気108 土	#2352 ¥14.4 ¥22 ×1 -¥28.6 ~ 应付¥32.4 全部のたびを 全部のたびを ないのため たごのたば ないのため ないのでの ないのため ないのでの ないの ないの ないの ないの ないの ないの ないの ない
2014 2017 201	#### (二一键取数 一一键取数 一一键取数 「 「 一一键取数 「 「 一 一 一 一 一 一 一 一 世 取数 一 一 一 世 取数 一 一 世 取数 一 一 他 取数 一 一 他 取数 一 一 他 和数 一 " 小 少 祖 / 一 武 (助) 二 一 一 一 (動) 二 一 一 (動) 二 一 一 (動) 二 一 一 (動) 二 一 一 (動) 二 一 一 (動) 二 一 一 (動) 二 一 一 (動) 二 一 一 一 一 (動) 二 一 一 一 一 (動) 二 一 一 一 一 一 一 一 一 一 一 一 一 一	#236# ¥14.4 ×22 ×1 -¥28.6 ~ 应付 ¥32.4 全部のものてた地下230 本部代意人形法 630669 総代手出「234***1234 大部代意人形法 630669 総代手れ「5、保学職紙 2015年で、服労で発す
Image: Image	#### (二一健取数) 構之海生酪拿铁 冰/少祖/微认奶油 夢后价 創に区 空気(5)108 土	#335# ¥14.4 ¥22 × 1 - ¥28.6 ~ 应印 ¥32.4 应印 ¥32.4 注意(50-1072/hg 123) *** (失生) 123****1234 天朝代書人氏波 63969 湯符単11号,保約報報 加請果若,服必有報 2022-11-10 15.37:37
Image: Image	#### <u>一一健取後</u> 着之海生酪拿铁 冰/少甜/默认奶油 夢后价 動EEE 望天知108 土	#2352 #14.4 422 ×1 -¥28.6 × 应付¥32.4 立印花述 全国代¥32.4 文印花述 60969 総代手出号、保护職権 近日年末、展为代報 002 34.2* 0630 复制 2022-11-10 15.3*.37 正は支付

Customer Side Operation Process:



5.3 Operations Side

After entering the backend management system, you can query and add maps in the "Map Management" section of the left menu bar.

GOOSEBOT 配送机器	人云平台				管理员 🗸
 高家账户管理 机器人管理 机器人操控 地器管理 	地图名称 查询	输入地图名称			
▲ 语音播报管理		# 地图名称	地图系数	地图	操作
		1 地图1	1.90	類語	编辑 更多 ~
		2 地图1	1.90	職	编辑 更多 >
		3 地图1	1.90	342	編輯 更多 >
		4 地图1	1.90	State.	編辑 更多 >
		5 地图1	1.90	職	编辑 更多 >>
		6 地图1	1.90	職	编辑 更多 >>
		7 地图1	1.90		編辑 更多 >
			く上一頁】1 下一頁 >		

In the "Robot Management" section of the left menu bar, you can query and add robot statuses, view the robot's panoramic environment in real time, conduct voice calls, and perform one-click recalls.



F.74 000

右

△ 语音播报管理

0

前

2022-10-12 12:00 2022-10-12 12:00



۲

+

里程: 35km

系统故障

系统故障

▲ 系统消息

简家账户管理			1						
机器人管理	机器人编号	输入编号查询		系统编号 输入商	豚名称		位置 请选择		~
机器人描控		07.144							
地图管理	查询	新增							
语音播报管理		机器人编号	系统编号	车辆状态	位置	电量	里程	速度	操作
	0 1	60669	SG123	自动	望京50HO	80%	100KM	25km/h	編領 更多 ~
	2	60669	SG123	人工	望京SOHO	80%	100KM	25km/h	编辑 更多 ~
	3	60669	5G123	自动	望京SOHO	80%	100KM	25km/h	編辑 更多~
	. 4	60669	SG123	λI	望京SOHO	80%	100KM	25km/h	编辑 更多 ~
	5	60669	SG123	自动	望京SOHO	80%	100KM	25km/h	编辑 更多 ~
	6	60669	SG123	自动	望京SOHO	80%	100KM	25km/h	编辑 更多 ~
	0 7	60669	SG123	自动	望京SOHO	80%	100KM	25km/h	「編輯」 更多 ~

In the "Merchant Account Management" section of the left menu bar, you can query and add merchant information.

商家账户管理	_						
机器人管理	商家账户	入账户查询	商家名称	输入商家名称	用户状态请	选择	~
机器人摸控	and the second sec						
地图管理	查询	新增					
语音播报管理	. #	商家名称	登录账户	用户类型	注册时间	用户状态	操作
	1	商家名称12	130-0000-8888	企业用户	2022-10-15	离线	编辑 更多 ~
	2	商家名称12	130-0000-8888	企业用户	2022-10-15	离线	编辑 更多 ~)
	3	育家名称12	130-0000-8888	企业用户	2022-10-15	在线	編辑 更多 ~
	4	商家名称12	130-0000-8888	企业用户	2022-10-15	高线	编辑 更多 ~
	5	商家名称12	130-0000-8888	企业用户	2022-10-15	离线	編辑 更多 ~
	6	商家名称12	130-0000-8888	企业用户	2022-10-15	在线	编辑 更多 ~
	0 7	商家名称12	130-0000-8888	企业用户	2022-10-15	在线	「编辑」 更多 ~

Stone-01 supports preset area looping and task execution, like playing audio or taking photos while moving.

Before setting up voice broadcast tasks, audio materials must be uploaded to the Stone-01 delivery robot cloud platform.

*Note: Before setting up voice broadcast tasks, audio materials must be uploaded to the Stone-01 delivery robot cloud platform in advance.

GOOSEBOT 配送机器	8人云平台				管理员 🗸
 ☞ 隆家能戶管理 ☆ 机器人管理 ご 机器人装控 = 地图管理 	语言名称查询	输入语音名称			
合 语音播报管理		#	语言名称	创建时间	操作
		1	防疫通知	2022-10-20 12:00	(编辑) 更多 ∨
		2	活动通知	2022-10-20 12:00	編輯 更多 ~
		3	防疫通知	2022-10-20 12:00	編辑 更多 ~
		4	活动通知	2022-10-20 12:00	编辑 更多 ~
		5	防疫通知	2022-10-20 12:00	編辑 更多 ~
		6	活动通知	2022-10-20 12:00	编辑 更多 ~
		7	活动通知	2022-10-20 12:00	(編輯) (更多 ~)
				< 上一丸 1 下一丸 >)	

The operation process for the Stone-01 delivery robot operations side is shown in the following diagram:

运营端(管理平台)		
		Not Not Not See all Image: See all Image: See all Image: See all See all Image: See all Image: See all Image: See all Image: See all Image: See all <